

Scheme Axle

MTE User Manual - Classification Schemes

4.03

MetroCount

Australia

15 O'Connor Close
North Coogee WA 6163
Ph: 08 9430 6164
Fax: 08 9430 6187
Email: sales@metrocount.com

United Kingdom

Unit 15, Oliver Business Park
Oliver Road
Park Royal, London NW10 7JB
Ph: 020 8782 8999
Fax: 020 8782 8737
Email: uksales@metrocount.com

United States

11820 West Market Place, Suite M
Fulton MD 20759
Ph: 800 576 5692
Fax: 301 490 3521
Email: usasales@metrocount.com

www.metrocount.com

Scheme Axle

Simply the number of axles in the vehicle.

- **Units:** Metric (m)
- **Car class:** 2
- **Unclassifiable vehicle class:** 12

Class	Name	Axles	Aggregate
1	1Ax	1	1
2	2Ax	2	2
3	3Ax	3	3
4	4Ax	4	4
5	5Ax	5	5
6	6Ax	6	6
7	7Ax	7	7
8	8Ax	8	8
9	9Ax	9	9
10	10Ax	10	10
11	>10Ax	>10	11

www.metrocount.com

Copyright© 1991, 2013 Microcom Pty Ltd. All rights reserved. MetroCount, Traffic Executive, MCSetup, MCSetLite, MCRReport, MCTools, Microcom and Microcom Pty Ltd, and the MetroCount and Microcom Pty Ltd logo, are trademarks of Microcom Pty Ltd. All other trademarks are the property of their respective owners. Other Microcom intellectual property including Patents and designs may be protected by international law. The furnishing of this software, the accompanying product or any related documentation or materials does not give you any license to this intellectual property.