Estimated Mass

MTE User Manual - Report Profiles

4.03

MetroCount

Australia
15 O'Connor Close
North Coogee WA 6163
Ph: 08 9430 6164
Fax: 08 9430 6187
Email: sales@metrocount.com

United Kingdom
Unit 15, Oliver Business Park
Oliver Road
Park Royal, London NW10 7JB
Ph: 020 8782 8999
Fax: 020 8782 8737
Email: uksales@metrocount.com

United States
11820 West Market Place, Suite M
Fulton MD 20759
Ph: 800 576 5692
Fax: 301 490 3521
Email: usasales@metrocount.com

www.metrocount.com

Estimated Mass

MCReport provides basic support for estimated pavement loading calculations, based on the volume and class distribution of traffic. The **Mass** page of the Advanced Profile options provides a table to enter estimated standard axles, freight mass and gross mass, per class of vehicle.

Estimated Mass table

To edit a row in the table, simply double-click. Units will be kilograms (kg) or pounds (lb) per the units option in the Advanced Profile's **General** page.

Editing mass table rows

Note that this table is closely linked to the selected classification scheme, and may differ between regions and counties that use the same classification scheme. Values are normally derived from weigh-station data of regional vehicle types, and their freight and gross mass.

Reports that use the Estimated Mass table include the **Custom List** report, and **Daily Classes (Estimated Mass).**

www.metrocount.com