# MetroCount®
## traffic data specialists

# Speed
## MTE User Manual - Classification Reports
4.03

**MetroCount**

Australia
15 O'Connor Close
North Coogee WA 6163
Ph: 08 9430 6164
Fax: 08 9430 6187
Email: sales@metrocount.com

United Kingdom
Unit 15, Oliver Business Park
Oliver Road
Park Royal, London NW10 7JB
Ph: 020 8782 8999
Fax: 020 8782 8737
Email: uksales@metrocount.com

United States
11820 West Market Place, Suite M
Fulton MD 20759
Ph: 800 576 5692
Fax: 301 490 3521
Email: usasales@metrocount.com

www.metrocount.com

# Speed

The Speed report is a time-based plot of average vehicle speed per selected integration period. By default, the report also shows a plot of maximum vehicle speed, and a horizontal marker for the posted speed limit (PSL).



**Speed Report sample, with mean, 85th percentile and maximum speed.**

Right-clicking on the report and selecting **Properties** displays the report's options.



**Speed report options**

**Show Min trace** displays a plot of minimum speed per integration period. **Show Percentile** displays a plot for the first percentile, and **Show Extra Speed Limits** displays horizontal markers for each of the speed limits, per the settings in the **Speed** page of the report's Advanced Profile options.

The **Annotation at marker** is a piece of text that appears next to the time of the marker, which can be placed with the cross-hairs. The drop-down list is also user-editable.

The Speed report also has two special **Display Span** options for a **Virtual Day** or **Virtual Week.**

# www.metrocount.com