

# Getting Started with Data Analysis

---

## MTE User Manual

3.21

June 2009

# Overview

---

MCRReport is the data analysis component of MTE. The power of MCRReport lies in the time-stamped raw data produced by MetroCount RSUs. MCRReport takes the raw sensor-hit stream stored in MetroCount data files, also known as **datasets**, and interprets the data to produce almost any conceivable report.

This section introduces the process of generating a report using the **Report Wizard**.

# New User Options


## Starting MCRReport

MCRReport has a huge array of options relating to classification, binning and filtering of vehicles, and to the formatting of reports. Most options have generic default values, however the default units of measurement and default classification scheme are highly region-specific. MCRReport also requires a location to create folders for working files, such as data files, Profiles and saved reports. The first time MCRReport is run after a new installation, two dialog boxes will be displayed, providing an opportunity to set these options.



### To start MCRReport


1. Run MCRReport from the **Start Menu** by locating the **MetroCount v3xx** folder, and selecting **MCRReport**. If this is the first time MCRReport or MCSetup have been run, the **New User File Setup** dialog box will be displayed.



### Setting a working folder location

2. MTE needs a folder location to store working files, such as MetroCount data, Profiles and templates. The default working folder location will be the current user's **Documents** folder. This is highly recommended as it is guaranteed to be accessible under all versions of Windows. To select a different folder, click the ... button.

Click the **OK** button, and MCRReport will create the list of folders shown in the sub-folders tree, and copy a set of default working files. When copying is complete, the **New User Options** dialog box will be displayed.




### MCReport's New User Options

3. Leave the **Use metric measurement units** option checked for metric (**km/h**), or uncheck it for non-metric (**mph**).  
This only affects the values in reports - MCReport always performs calculations using SI units.
4. Select a Classification Scheme from the list provided.  
The list of schemes is MCReport's built-in OEM classification schemes. A range of user-editable External Schemes can be selected from later.
5. The final option is the Header Page text, which appears at the top of every report. A company, council or county name may be appropriate.
6. The **Show all the options** check box at the bottom will display the Default Profile after the **OK** button is clicked. Again, this can be easily accessed later.

# Generating a Report

## The Report Wizard

Generating a report with the **Report Wizard** is an incredibly simple process, illustrated by the following diagram.



**Generating a Report with the Report Wizard**

The **File Management List** is a temporary list of datasets that have been loaded, ready for analysis. Datasets can be loaded into the File Management List via MCRReport's **File Tree** window, or from a list of recently used datasets. Datasets can then be selectively **tagged** for inclusion in the report being generated.

The **Report Vortex** contains the list of available reports, firstly grouped by their mode of analysis (Classification or Event Count) and then by the format of the report (Tables, Charts or Special).

A **Profile** in MCRReport encompasses the set of vehicle filter, classification, statistical and formatting options for each report. When a new report is generated, a copy of MCRReport's **Default Profile** is attached to the report and is referred to as the report's **Local Profile**. This is displayed as part of the


Report Wizard, with the most frequently used vehicle filter settings easily accessible.

The end result is an automatically formatted report, that can be printed or saved. Note that the Local Profile, or list of tagged datasets can be easily accessed via the report's right-click menu, without repeating the entire Report Wizard. Many reports also have interactive tools for examining detail.



## To generate a report


1. Start MCRReport, and if necessary set the New User options as described in the previous section.
2. Click the **New Report** button on MCRReport's main toolbar.



### Starting the Report Wizard


3. For this simple example, load the **urbanhwy.ec0** sample dataset that is always available in the **Recent Files** drop-down list at the bottom. Loading files using the **File Tree** is covered in the next section.

Once the file is loaded, note the red arrow next to the dataset, indicating it is **tagged** for this report. Click the **Next** button to continue.



### Load a dataset

4. Select a report, such as **Weekly Vehicle Counts**, and click the **Next** button.




Select a report



- The report's **Local Profile** is now displayed. Notice that each setting is a button, which will open another dialog box for editing that setting. Also note the **Advanced** button at the top, which leads to numerous, but infrequently accessed options.

For this example, simply accept the defaults by clicking the **Next** button.




The screenshot shows a dialog box titled "Report profile" with a sub-header "Vehicle and report settings". Below the sub-header is a small image of a city skyline. The main content area contains several settings, each in a button-like format:

- Name:** Default Profile (with an "Advanced..." button to its right)
- Speed:** Include vehicles with speeds between 10 km/h and 160 km/h.
- Separation:** No filter on Separation - (Headway)
- Direction:** North, East, South, West bound.
- Classes:** Include class 1, 2, 3, 4, 5, 6, 7, 8, 9, 10, 11, 12
- Scheme:** Classified vehicles - ARX
- Time:** From 13:00 Monday, 20 September 1993 to 14:24 Monday, 27 September 1993

At the bottom of the dialog, there is a checkbox labeled "Disable filter" and two buttons: "<< Back" and "Next >>".

### View Local Profile


- The selected report is now generated and displayed, ready to be printed or saved. Try right-clicking anywhere within the report, and note the options in the pop-up menu. **Local Profile** will display the report's current Profile, then recalculate. **Datasets** will display the **File Management List**, where the tagged datasets can be changed and the report regenerated.



The generated report, showing right-click menu



# File Tree Basics

MReport's File Tree window is the primary tool for browsing, searching and auditing MetroCount datasets. Files are listed, and sortable, by their key header details, rather than their physical file attributes. Folders containing MetroCount datasets are marked with a special green icon in the folder tree for easy identification. The File Tree is also the best method for loading datasets into the File Management List.



**File Tree Window**

Double-clicking a dataset in the File Tree displays the dataset's header details and properties, grouped into several pages. The **Hits** page is extremely useful for rapidly assessing basic data quality.




## Dataset Properties




### To load files into the File Management List

1. Open a File Tree window by clicking the **New File Tree** button on MCRReport's main toolbar.
2. To locate some sample datasets, click the **Favourites** button, and select **MTE Samples**. This automatically selects the **Samples** folder in MTE's working folder location.




### Locating the Samples folder

3. Select a couple of the sample files (hold down the **Ctrl** or **Shift** key to select multiple files), and click the **New report** button.



### Loading the selected files

4. Click the **Yes** button to load the files.
5. The Report Wizard is now started, with the selected datasets loaded. Notice files are not tagged by default. Simply double-click them to tag for the next report.



**Tag files and continue the Report Wizard**


# File Management List

## Overview

The File Management List contains a list of datasets that have been loaded into memory, ready for analysis. Datasets are *tagged* for inclusion in a report, as indicated by the red arrow icon. The File Management List is displayed as part of the Report Wizard when generating a new report, or when swapping datasets on an existing report.

The File Management List is a temporary list. Loaded datasets remain in the list for the current session of MCRReport, or until they are explicitly removed. The list may contain up to 16 datasets.

Most reports support tagging of multiple datasets. This may be required for combined, multi-lane analysis where a single RSU was used per lane, and for time-contiguous datasets for a single site.



File Management List, with right-click menu

## Adding Datasets

There are several methods for loading datasets into the File Management List:

- via the File Tree,
- using the **Recent Files** list, or
- drag-and-drop.

The File Tree is the recommended method. Selecting files in a File Tree window, then clicking the **New Report** button will load them into the File Management List, up to a maximum of 16 datasets.

The **Recent Files** list, located at the bottom of the File Management List, contains the 10 most-recently loaded datasets.

Dragging files from another application is also supported. Files must be dropped on the title bar of MCRReport's main window.

# Tagging Datasets

Tagged datasets are indicated by the red arrow icon next to their file name. At least one dataset must be tagged to generate a report.

To toggle the tagged status of a dataset, simply double-click it. To toggle a group of datasets, select them, and then select **Tag/Untag** from the right-click menu.

Note that some reports do not support multiple datasets. Selecting one of these reports in the Report Vortex will display a warning, and return to the File Management List.


# Removing Datasets

Manually removing datasets from the File Management List is only required if the list is full. Simply select at least one dataset, right-click and select **Remove**.

A dataset can not be removed if it is tagged, or it is in use by an open report (indicated by the blue bar icon). To remove, firstly close any reports using that dataset.

# Dataset Spans

The **Spans** button in the File Management List displays a chart of the relative time-spans for the loaded datasets. The chart is scaled from the earliest start time to the last finish time, with each dataset represented by a red bar. Each dataset's blue line represents the time between the first and last sensor hits.



**Time-spans of datasets in the File Management List**




# Report Types

## Overview

The **Report Vortex** is the report selection stage of the Report Wizard. Reports are primarily grouped by their mode of analysis, **Classification** or **Event Count**, represented by the two pages at the top. Reports are then sub-grouped by output format:

- **Tables** - pre-formatted, paginated text reports, and continuous text reports with user-definable columns and export options.
- **Charts** - graphical reports, such as pie charts, time-based plots, dispersion plots and data-audit charts.
- **Special** - generic and "standard" report formats.



### Selecting a report



*Note: The **Remember last position** option automatically selects the last report that was generated - useful when generating several of the same report.*

# Classification versus Event Count Reports

## Classification Analysis

Classification analysis requires datasets collected using a Classifier Layout, where the A and B axle sensors are placed in parallel and a known distance apart. From this, MCRReport derives **vehicles**.

Firstly, MCRReport performs the complex task of examining the raw data and partitioning groups of sensor hits into likely vehicles. This is based on a number of time and distance parameters determined by MCRReport.

The next step is to determine the axle configuration of each vehicle. The first A and B hit pair in the group determines the direction of the vehicle, and the speed of the vehicle, based on the sensor spacing. From the speed, the time between the remaining hit pairs determines the spacing between axles.

The final step is to apply a classification scheme, based on the axle spacings in the vehicle. MCRReport offers a choice of standard and special-purpose classification schemes, called **OEM Schemes**. Other classification schemes can be added to MCRReport using user-definable **External Schemes**.

From here, the set of vehicles can be filtered, and formatted into a vast array of reports.

## Event Count Analysis

Event Count analysis treats the raw A and B sensor hits as user-selectable events - usually counts. MCRReport refers to the definition of an event as the **Count Method**, which may be one of the following:

- raw counts,
- counts divided by 2,
- counts divided by a custom factor,
- gaps above a certain length (in seconds), or
- following gaps, defined as a starting gap and a following gap.



Datasets collected using a Count Layout should only be analysed using Event Count reports. Attempting to analyse this type of data as vehicles will produce meaningless results.

Classifier Layout datasets can be optionally analysed with Event Count reports. These may be useful for obtaining approximate counts for periods where one sensor has failed, or for gap analysis.

## Multi-file Reports



Most reports support inclusion of multiple datasets in a single report. This may be necessary for combining results from multi-lane sites with one RSU per lane, and for time periods spanning multiple datasets.

There is an icon next to each report in the Report Vortex, indicating multi-file support as shown in the following table.

Icon	Description
	Report supports single dataset only
	Report supports multiple datasets

## Dataset Signatures

MetroCount datasets contain a digital Signature, which controls access to reports in the Report Vortex. A dataset's Signature *type* is inherited from the RSU that created it, such as **Plus** and **Regular**. The Signature type is one of the columns in both the File Tree and the File Management List.

Icon	Description
	Report available
	Report unavailable due to incompatible dataset Signature type

Reports that are unavailable due to an incompatible Signature type are indicated by a lock icon next to the report name. Selecting one of these reports and clicking the **Next** button will display a message indicating the required Signature type to use that report.




### Signature type incompatible

When tagging multiple datasets, report availability will be determined by the lowest Signature type.

# Profiles

## Overview

A Profile in MCRReport is the set of vehicle filter, classification, statistical and formatting options common to all reports. Each report has its own **Local Profile**, which is copied from the **Default Profile** when the report is generated. A report's Local Profile is presented as part of the Report Wizard, and can be accessed at any time via the report's right-click menu.




**Report Profile**

Profiles are designed to be only as complex as they need to be. There is an enormous amount of information that can be derived from time-stamped raw data, which means a lot of options. MCRReport logically groups these options into the more frequently accessed **vehicle filter** settings on the primary page, with other options categorised under the **Advanced** options. The Advanced options tend to be those that will be set once in the Default Profile, then rarely modified.

MCRReport uses a reasonable set of values for the Default Profile after a new installation. These settings are based on the classification scheme and units of measurement selected in the **New user options** when MCRReport is run for the first time.

## Working with Profiles

Profiles can be saved to create a library of commonly used filters and options. Profiles can also be easily copied amongst open reports to ensure a consistent set of vehicles are included. These features are accessed via a Profile's menu button in the top right-hand corner.




### Profile menu

Saved Profiles are stored in files with a **.ini** extension, and located in the **Profiles** folder under MTE's working folder location. When a Profile is saved, all of the options are written to the file. When loading a Profile, different groups of option can be selectively loaded.



## To modify a report's Local Profile

1. Right-click on a report and select **Local Profile** from the pop-up menu.



The generated report, showing right-click menu


2. Modify the Profile as required, and click the **OK** button. The report will be automatically regenerated.

*Note: Regenerating a report, such as by editing the Local Profile, will lose any manual text editing.*



## To set a Profile as the Default Profile

1. Edit a report's Profile, and select **File » Save to default** from the Profile's menu button.
2. To make the current Profile the permanent default, click the **Yes** button. Clicking **No** will change the Default Profile only for the current session of MCRreport.



**Permanently save changes**



### To save a Profile

1. Edit a report's Profile.
2. Select **File » Save Profile** from the Profile's menu button.
3. Enter a descriptive file name for the Profile (the name of a Profile can optionally be displayed in the header of a report), and click the **Save** button.




### To load a Profile

1. Edit a report's Profile, and select **File » Load Profile** from the Profile's menu button.
2. Select a Profile, and click the **Load** button.
3. The **Merge Profile** dialog box lists the groups of options that can be selectively loaded.

The default is to include all options, except the time range. This is because the start and finish times in the saved Profile are from the datasets that were tagged when the Profile was originally saved, and usually need to be ignored.

Click the **Load** button to apply the selected options.



### Selectively loading parts of a Profile



### To copy a Profile

1. Edit the source report's Profile, and select **Edit » Copy** from the Profile's menu button.
2. Exit the Profile by clicking the **Cancel** button.
3. Edit the target report's Profile, and select **Edit » Paste** from the Profile's menu button.



**www.metrocount.com**

Copyright© 1991, 2009 Microcom Pty Ltd. All rights reserved. MetroCount, Traffic Executive, MCSetup, MCSetLite, MCRReport, MCTools, Microcom and Microcom Pty Ltd, and the MetroCount and Microcom Pty Ltd logo, are trademarks of Microcom Pty Ltd. All other trademarks are the property of their respective owners. Other Microcom intellectual property including Patents and designs may be protected by international law. The furnishing of this software, the accompanying product or any related documentation or materials does not give you any license to this intellectual property.